


WIRING SCHEMATIC



PARTS LIST

1. 2.5-Gal. Air Tank
2. Air Compressor
3. Drain Cock
4. Compressor Leader Hose
5. 1/4-inch Compression Fitting
6. 1/4-inch Quick Connect Coupler
7. Female Tee
8. Male Tee
9. Ring Terminal to Ignition
10. Positive Lead Wire
11. Dash Panel Gauge with ON/OFF Switch
12. Female Terminal Connector
13. Positive Extension Wire
14. 1/4-inch Air Line
15. Gauge Light Positive Wire (RED)
16. Gauge Light Ground Wire (BLACK)
17. Male Push-On Terminal Connector
18. Reducer (1/4-inch NPT to 1/8-inch NPT)
19. Pressure Switch with Relay
20. Insulated Terminal Connector
21. Grommet
22. Positive Lead Wire with Inline Fuse
23. Ring Terminal to Power Source